

Installation Manual

MAZDA 3 5DR
MAZ-3-5-C-18



SHADES

FIXING CLIPS



CL-M05 x 4



CL-T01 x 1



Side Shade Installation

MAZDA 3 5DR

MAZ-3-5-C-18

Components Needed:



CL-M05 x 4



CL-T01 x 1

STEP #1

INSERT CLIPS INSIDE WEATHERSTRIP



STEP #2

POSITION THE SIDE SHADE



STEP #3

ATTACH SIDE SHADE BEHIND CLIPS



STEP #4

ENSURE SECURELY FITTED IN PLACE

